




GP-0511/0511W DIE GRINDER



PARTS DESCRIPTION

NO.

01.	MOTOR HOUSING
02.	LEVER PIN
03.	AIR INLET
04A.	THROTTLE LEVER
04B.	SAFETY SWITCH
05.	VALVE STEM
06.	EXHAUST DEFLECTOR
07.	"O" RING
08.	VALVE SPRING
09.	"O" RING
10.	THROTTLE VALVE PLUG
11.	"O" RING
12.	ROTOR BUSH
13.	BALL BEARING
14.	REAR END PLATE
15.	ROTOR
16.	ROTOR BLADES (4)
17.	PIN (3)

PARTS DESCRIPTION

NO.

18.	CYLINDER
19.	FRONT END PLATE
20.	BALL BEARING
21.	AIR REGULATOR
22.	SPINDLE
22C8.	8mm COLLET SPINDLE
23.	RETAINER
24-1.	1/8" COLLET
24-2.	1/4" COLLET
24-3.	3mm COLLET
24-6.	6mm COLLET
24C8.	8mm COLLET
25.	COLLET NUT
25C8.	8mm COLLET NUT
26.	HOUSING CAP
27.	ANGLE SPANNER
28.	DOUBLE ENDED SPANNER
29.	RETAINER RING



Ph: 1300 792 997 or +61 7 3272 7999
 Fax: 1300 798 189 or +61 7 3272 7982
sales@air-allied.com.au www.air-allied.com.au