


GP-0516 UTILITY CUT-OFF TOOL



PARTS DESCRIPTION

NO.

01.	MOTOR HOUSING
02.	LEVER PIN
03.	AIR INLET
04A.	THROTTLE LEVER
04B.	SAFETY SWITCH
05.	VALVE STEM
06.	EXHAUST DEFLECTOR
07.	"O" RING
08.	VALVE SPRING
09.	"O" RING
10.	THROTTLE VALVE PLUG
11.	"O" RING
12.	ROTOR BUSH
13.	BALL BEARING
14.	REAR END PLATE
15.	ROTOR BUSH
16.	ROTOR BLADES (4)
17.	PIN (3)

PARTS DESCRIPTION

NO.

18.	CYLINDER
19.	FRONT END PLATE
20.	BALL BEARING
21.	AIR REGULATOR
22.	SPINDLE
23.	RETAINER
24.	GUARD
25.	HEX. SCREW
26.	NUT
27.	WASHER
28.	SPANNER
29.	RETAINER RING
30.	CUTTING WHEEL
31.	ALLENWRENCH
32.	SPRING
33.	SAFETY BAR
34.	SPRING PIN