




[www.air-allied.com.au](http://www.air-allied.com.au)

## GP-0580 AIR ENGRAVING STYLUS



<u>PARTS</u>	<u>DESCRIPTION</u>
<u>NO.</u>	
01.	BODY
02.	ADJUSTMENT NUT
03.	FRONT PART
04.	THROTTLE VALVE
05.	RING NUT
06.	VALVE SEAT
08.	"O" RING
09.	BUSH
10.	"O" RING
11.	SEAL
12.	SPRING WASHER
13.	"O" RING
14.	"O" RING
15.	AIR HOSE
17A.	SLEEVE FOR THIN POINT
17B.	SLEEVE FOR MEDIUM POINT
17C.	SLEEVE FOR LARGE POINT