



Parts List

| Index NO. | Part Number | Description | Q`ty rq`d |
|-----------|-------------|-----------------------|-----------|
| 1 | Y31014010 | Air Inlet PT | 1 |
| | Y3101401A | Air Inlet NPT | 1 |
| 2 | Y31010020 | Throttle Valve Cap | 1 |
| 3 | Y31014030 | Throttle Valve Spring | 1 |
| 4 | Y10103040 | Valve Ball | 1 |
| 5 | Y31014050 | Handle | 1 |
| 6 | Y31014060 | Throttle Valve Pin | 1 |
| 7 | Y31014070 | Cylinder Cap | 1 |
| 8 | Y31014080 | Lever Lock | 1 |
| 9 | Y10104040 | Spring Pin 4 × 25 | 1 |
| 10 | Y31014100 | Lever | 1 |
| 11 | Y31010110 | Valve Upper Seat | 1 |
| 12 | Y31010120 | Valve Center Seat | 1 |
| 13 | Y31010130 | Valve | 1 |
| 14 | Y31010140 | Valve Lower Seat | 1 |
| 15 | Y31010150 | Valve Knock Pin | 2 |

| Index NO. | Part Number | Description | Q`ty rq`d |
|-----------|-------------|-----------------------------|-----------|
| 016 | Y31010160 | Lock Nut | 1 |
| 017 | Y31010170 | Exhaust Band | 1 |
| 018 | Y31014180 | Cylinder | 1 |
| 019 | Y31010190 | Piston | 1 |
| 020 | Y31010200 | Double Nut | 1 |
| 021 | Y31010210 | Gland Nut | 1 |
| 022 | Y31010220 | Inner Bush | 1 |
| 023 | Y31010230 | Packing | 4 |
| 024 | Y31010240 | Outer Bush | 1 |
| 025 | Y31010250 | Butt | 1 |
| 026 | Y10301220 | Hose Stem PT3/8 × 1/2 | 1 |
| | Y31010260 | Hose Stem NPT3/8 × 1/2 | 1 |
| 027 | Y10601240 | O Ring S-18 | 1 |
| 028 | Y31014280 | Pipe | 1 |
| 029 | Y31014290 | Joint | 1 |
| 800 | Y3101405A | Handle CP (No.2~6, 8~10,27) | 1 |
| 801 | Y3101013A | Valve CP (No.11~15) | 1 |