EMERGENCY SWITCH

Brand: Toku   **Product Code: 136690502**

EMERGENCY SWITCH

This is the emergency stop switch (button) assembly for TOKU Pilot Pendant assemblies.